


STRETCH FABRIC TUBE BANNER

Assembly Instructions

Product Components


- ① Top Connector Pole - x1
- ② Top Corner Poles - x2
- ③ Side Poles (Elasticated) - x2
- ④ Bottom Corner Tubes - x2
- ⑤ Bottom Connector Pole - x1
- ⑥ Plate Connector Feet - x2
- ⑦ Plate Base - x1
- ⑧ Middle Crossbar - x1



①

Assemble the Top Arch


Connect the two numbered corner pieces to the top connector pole to form an arch.



②

Build the Side Poles


Click each section of the side poles together until both are solid and fully extended.




③

Attach Grey Caps

Click the grey caps onto the bottom of each side pole. Ensure the screw on the cap faces outward. Secure the remaining holes of the cap to the bottom crossbar.



4



Assemble the Frame


Connect all assembled parts. Attach the arch to the top and ensure the bottom is secured to the side poles.

Insert the middle crossbar between the side poles for extra support.

5

Fit the Graphic


Lay the frame down and pull the fabric over from top to bottom until taut. Zip closed along the bottom crossbar.




6

Prepare the Base

Use a screwdriver or Allen key to remove screws from the plastic feet.



7



Attach the Base Plates

Align each base plate with the holes in the feet and securely fasten.

8

Stand It Up

Lift the banner upright. You're ready to display your brand!

